



**CLASSIC MULTI-SLOT BASE
CLASSIC ALUMINUM BASE
CLASSIC ALUMINUM BASE PAIR
CLASSIC MUZZLELOADER BASE
GRANDSLAM STEEL DOVETAIL BASES
TACTICAL PICATINNY EXTENDED MULTI-SLOT BASES**

⚠ WARNING: UNLOAD FIREARMS BEFORE INSTALLATION TO PREVENT SHOOTING ACCIDENTS.

ASSEMBLY INSTRUCTIONS:

1. USE A PADDED VISE TO HOLD FIREARM STEADY AND REMOVE FILLER SCREWS FROM RECEIVER.

CLEAN FIREARM RECEIVER, RECEIVER BASE HOLES AND ALL MOUNT PARTS THOROUGHLY.

2. PLACE THE BASE(S) ON THE RECEIVER AND ALIGN HOLES.

INSERT MOUNT BASE SCREWS*.

TIGHTEN MIDDLE SCREW(S) FIRST AND THEN END SCREWS, BUT NOT FULLY TIGHTENED.

GO OVER THE ENTIRE SYSTEM, TIGHTENING ALL SCREWS AS TIGHT AS YOU CAN.

DO NOT EXERT ENOUGH TORQUE TO SNAP THE SCREWS.

NOTE: MANY GUNSMITHS ALSO APPLY A SMALL DROP OF THREAD ADHESIVE TO THE BASE SCREWS. (DO NOT ALLOW ADHESIVE TO GET INTO THE ACTION).

3. REFER TO RING AND SCOPE MANUFACTURE RECOMMENDED MOUNTING INSTRUCTIONS TO FINISH SCOPE INSTALLATION.

***SOME FIREARMS REQUIRE THE USE OF TWO DIFFERENT LENGTH BASE SCREWS. IF A BASE SHIPS WITH TWO DIFFERENT LENGTH SCREWS TYPICALLY THE SHORTER SCREWS ARE USED IN THE FRONT OF THE RECEIVER.**

https://www.weaveroptics.com/on/demandware.static/-/Library-Sites-HuntShootAccessoriesSharedLibrary/default/dwb30465c4/productPdfFiles/weaverPdf/weaver_torque_specs.pdf